




# SPARE PARTS LIST

LAWN MOWERS: CONSUMER  
WALK-BEHINDS

R147, 965159101, 2008-02



| Référence | Numéro de Pièce | Description              | Remarque | QTÉ Kit équipement |
|-----------|-----------------|--------------------------|----------|--------------------|
| 1         | 544 44 39-01    | ENJOLIVEUR               |          | 2                  |
| 2         | 504 85 78-01    | ÉCROU                    |          | 2                  |
| 3         | 502 44 56-01    | ROUE COMPLÈTE            |          | 2                  |
| 4         | 504 54 82-01    | ROULEMENT À BILLES       |          | 2                  |
| 5         | 544 43 28-01    | JOINT TORIQUE            |          | 2                  |
| 7         | 504 82 73-01    | PARE-POUSSIÈRE           |          | 2                  |
| 8         | 531 21 08-17    | RESSORT                  |          | 1                  |
| 9         | 531 20 84-92    | ÉCROU                    |          | 1                  |
| 10        | 531 20 79-86    | BOUTON                   |          | 1                  |
| 11        | 501 97 99-01    | LEVIER DE LEVAGE COMPLET |          | 1                  |
| 12        | 538 23 58-07    | VIS                      |          | 1                  |
| 13        | 504 80 01-01    | ESSIEU ARRIÈRE           |          | 1                  |
| 14        | 531 20 66-53    | AXE                      |          | 1                  |
| 18        | 531 20 59-44    | SUPPORT                  |          | 2                  |
| 21        | 544 44 40-01    | ENJOLIVEUR               |          | 1                  |
| 22        | 504 85 78-01    | ÉCROU                    |          | 2                  |
| 23        | 502 44 50-01    | ROUE COMPLÈTE            |          | 2                  |
| 24        | 504 54 82-01    | ROULEMENT À BILLES       |          | 2                  |
| 25        | 544 43 31-01    | JOINT TORIQUE            |          | 2                  |
| 26        | 531 20 50-57    | COUVERCLE                |          | 4                  |
| 27        | 544 45 91-01    | AXE                      |          | 1                  |
| 28        | 531 20 66-53    | AXE                      |          | 1                  |
| 30        | 531 20 80-08    | VIS                      |          | 1                  |
| 31        | 531 20 72-37    | RONDELLE                 |          | 1                  |
| 32        | 581 18 89-10    | MOWER BLADE              |          | 1                  |
| 33        | 531 20 72-43    | RONDELLE                 |          | 1                  |
| 34        | 531 20 50-48    | ADAPTATEUR               |          | 1                  |
| 35        | 531 20 49-07    | TOUCHE                   |          | 1                  |
| 51        | 531 20 83-00    | LEVIER                   |          | 1                  |
| 52        | 531 20 83-06    | SAC                      |          | 1                  |
| 53        | 531 20 82-96    | CARTER                   |          | 1                  |
| 54        | 531 21 11-84    | RESSORT                  |          | 1                  |
| 55        | 531 21 06-17    | BOUCHON                  |          | 1                  |
| 58        | 531 20 59-81    | CARTER                   |          | 1                  |
| 60        | 531 20 82-16    | VIS                      |          | 2                  |
| 61        | 531 20 88-44    | VIS                      |          | 4                  |
| 62        | 531 21 24-78    | DECAL                    |          | 1                  |
| 63        | 531 21 39-01    | DECK                     |          | 1                  |
| 64        | 531 21 28-51    | VIS                      |          | 3                  |
| 65        | 531 20 58-48    | CONNECTEUR               |          | 1                  |
| 66        | 531 21 08-24    | BAGUE DE RETENUE         |          | 2                  |
| 67        | 531 21 14-41    | SUPPORT                  |          | 1                  |
| 68        | 531 21 18-40    | RESSORT                  |          | 1                  |
| 70        | 531 21 37-83    | RESSORT                  |          | 1                  |
| 71        | 531 21 05-87    | BARRE                    |          | 1                  |
| 80        | 531 20 58-40    | BOUTON                   |          | 2                  |
| 81        | 531 20 49-22    | RONDELLE                 |          | 2                  |
| 82        | 531 21 14-74    | SEGMENT                  |          | 2                  |
| 83        | 531 21 14-76    | RESSORT                  |          | 2                  |
| 84        | 531 21 14-73    | SEGMENT                  |          | 2                  |
| 85        | 531 21 15-81    | PLAQUE                   |          | 2                  |
| 86        | 531 21 14-80    | VIS                      |          | 2                  |
| 88        | 531 20 84-91    | ÉCROU                    |          | 2                  |
| 89        | 531 20 49-61    | RONDELLE                 |          | 4                  |
| 90        | 531 20 71-65    | ÉCROU                    |          | 2                  |
| 91        | 531 20 51-69    | PIN RETAINING SCREW      |          | 2                  |
| 93        | 531 21 07-25    | PROTECTOR                |          | 1                  |
| 94        | 531 20 58-63    | OUILLET                  |          | 1                  |
| 95        | 531 21 20-39    | POIGNÉE                  |          | 1                  |
| 98        | 531 20 55-81    | COLLIER DE SERRAGE       |          | 2                  |
| 100       | 531 21 35-17    | VIS                      |          | 1                  |
| 102       | 531 21 35-22    | CABLE DE FREIN           |          | 1                  |
| 103       | 531 20 80-43    | SUPPORT                  |          | 1                  |
| 104       | 531 20 84-91    | ÉCROU                    |          | 1                  |